Sperry Marine UK

Service Bulletin No.9 (Release 3)

Product: Decca BridgeMaster E Series Radars

Subject: List of Current Manuals

The following is a list of all the BridgeMaster E series manuals currently in publication (latest issues stated).

Name of Manual	Part Number	Comments
Bridge Card	65800008-4	Covers software versions 4.xx, 5.xx and AIS
User Guide	65800010A-6	Covers software versions 4.xx, 5.xx and AIS
Ship's Manual	65800010B-3	
Technical Manual	65800011-1	Clave Junction Boy & Dodor Clave Interface added
Ancillary Units	65800012-5	Slave Junction Box & Radar Slave Interface added
Special Naval Features*	65800013-1	Addendum to User Guide
Additional Facilities	65800015	Addendum to Ship's Manual
Flat Panel Display Monitors	65800016	Addendum to Ship's Manual
Remotely Selectable Antenna Speed	65800017-1	Addendum to Ship's Manual
Bridge Card	65818007	Dual Channel
Bridge Card*	65818008-1	Tactical Displays
User Guide*	65818010A-2	Tactical Displays Single Channel variant
Technical Manual*	65818010B-1	Tactical Displays
User Guide	65818014A-1	Dual Channel
Ship's Manual	65818014B	Dual Channel Supplement
Tactical Displays*	65818017-1	Addendum to Ship's Manual
Technical Manual*	65825010-4	25kW I Band Transceivers 65825 CA, CB & CC
Technical Manual*	65851011-1	RRB Associated Equipment

The following manuals are available on CD Rom:

Bridge Card (65800008-3), User Guide (65800010A-4) and Ship's Manual (65800010B-3). Part Number: **65800030**

Technical Manual (65800011-1) and Ancillary Units (65800012-3). Part Number: **65800031**

Special Naval Features (65800013-1). Part Number: **65800032***

* EXPORT LICENCE IS REQUIRED