

Thank you for purchasing this Factory Service Manual CD/DVD from [servicemanuals4u.com](http://servicemanuals4u.com).

Please check out our eBay auctions for more great deals on Factory Service Manuals:

[servicemanuals4u](http://servicemanuals4u)

# maintenance & service guide


## Presario 1400 Series

**Model XL240, XL241, XL242, XL244, XL245, XL246, XL247, XL250, XL340, XL341, XL342, XL343, XL344, XL345, XL346, XL350, XL352, XL355, and XL356**

## Pin Assignments


This section provides connector pin assignment tables for Compaq Presario 1400 Series Portable Notebook. For additional information on connectors, refer to the sections on [Rear Connectors](#).

### Modem



Modem	
1	Ring
2	Tip

### Universal Serial Bus



Universal Serial Bus			
1	Power	4	Ground
2	Data -	5	Ground
3	Data +	6	Ground


**1.800.AT.COMPAQ**

# maintenance & service guide

## Presario 1400 Series

Model XL240, XL241, XL242, XL244, XL245, XL246, XL247, XL250, XL340, XL341, XL342, XL343, XL344, XL345, XL346, XL350, XL352, XL355, and XL356

### *External Monitor*



External Monitor	
1	Red
2	Green
3	Blue
4	N/C
5	Ground
6	Ground
7	Ground
8	Ground
9	Power
10	Ground
11	N/C
12	SDA
13	Hsync
14	Vsync
15	SCL

# maintenance & service guide

## Presario 1400 Series

Model XL240, XL241, XL242, XL244, XL245, XL246, XL247, XL250, XL340, XL341, XL342, XL343, XL344, XL345, XL346, XL350, XL352, XL355, and XL356

### *RJ-45 (NIC)*



RJ-45 (NIC)	
1	8PMJ-1
2	8PMJ-2
3	8PMJ-3
4	8PMJ-4
5	8PMJ-5
6	8PMJ-6
7	8PMJ-7
8	8PMJ-8

# maintenance & service guide

## Presario 1400 Series


Model XL240, XL241, XL242, XL244, XL245, XL246, XL247, XL250, XL340, XL341, XL342, XL343, XL344, XL345, XL346, XL350, XL352, XL355, and XL356

### *S-Video*



S-Video	
1	Y/R
2	C/G
3	Ground
4	Ground

### *AC Adapter*



AC Adapter	
Center Pin	Power
Outside Pin	Ground