
## 2004 > G 2.0 DOHC > Body Electrical System





- 1. Disconnect the wire connector(B) from the ETACS module(A).
- 2. Inspect the connector(B) on wire harness side as shown in the below.



Terminals No.	Test condition	Standard value
A18-A16 (GND)	Door switch "ON" (Door opened)	Below 1
	Door switch "OFF" (Door closed)	1M or higher
A10-A16 (GND)	Luggage compartment door switch "ON" (Luggage compartment door opened)	Below 1
	Luggage compartment door switch "OFF" (Luggage compartment door closed)	1M or higher
C7-A16 (GND)	Engine hood switch "ON" (Engine hood opened)	Below 1
	Engine hood switch "OFF" (Engine hood closed)	1M or higher
A8-A16 (GND)	Driver's door switch "ON" (Driver's door opened)	Below 1
	Driver's door switch "OFF" (Driver's door closed)	1M or higher
A9-A16 (GND)	Assist door switch "ON" (Assist door opened)	Below 1
	Assist door switch "OFF" (Assist door closed)	1M or higher

B2-A16 (GND)	Door warning switch "ON" (Key inserted)	Battery voltage
	Door warning switch "OFF" (Key removed)	Below 1V
C10-A16 (GND)	Trunk key unlock switch "ON" (Trunk lid is unlocked with key)	Below 1
	Trunk key unlock switch "OFF"	1M or higher
A1-A16 (GND)	Always	Battery voltage
A6-A16 (GND)	Ignition switch is turned to "ON" position	Battery voltage
B5-A16 (GND)	Driver's door lock switch "ON" (Driver's door unlock detection)	Below 1
B3-A10 (GND)	Driver's door lock switch "OFF" (Driver's door lock detection)	1M or higher
B6-A16 (GND)	Assist door lock switch "ON" (Assist door unlock detection)	Below 1
	Assist door lock switch "OFF" (Assist door lock detection)	1M or higher
A3-A16 (GND)	Rear door lock switch "ON" (Rear door unlock detection)	Below 1
	Rear door lock switch "OFF" (Rear door lock detection)	1M or higher
C8-A16 (GND)	Always	Battery voltage
C12-A16 (GND)	Engine Start	Battery voltage
A16(GND) - Body ground	Always	Below 1
C9-A16 (GND)	Siren operation	ON
C5-A16 (GND)	Driver's door key unlock switch "ON" (Driver's door is unlocked with key)	Below 1
C6-A16 (GND)	Driver's door key lock switch "ON" (Driver's door is locked with key)	Below 1