2004 > G 2.0 DOHC > Heating, Ventilation, Air Condioning	
DESCRIPTION	
There should be continuity between No.3 and No.4 terminals when power and ground are connected to the	ne No.1
and No.2 terminals, and there should be no continuity when power is disconnected.	
-Rated voltage : DC 12V	
-Operation voltage range : DC 10V ~ DC 15V	
-Rated load current : DC 12V, 25A (Motor lord)	